

# REVEAL

windows & views

adam frank  
INCORPORATED

## Directions

- 1 Turn projector off and unplug.
- 2 Loosen lens locking screw.
- 3 Remove lens assembly from projector body completely.
- 4 Place lens assembly on a flat surface, lens down.
- 5 Move chains away from slides and over holding ring.
- 6 Rotate slide clips outward.
- 7 Remove all slides.
- 8 Choose a slide grouping.

First choose a window slide.





Stack two spacer rings then a view slide on top.

Make sure that the triangles on the slides point in the same direction.

- 9 Point the triangles directly away from the chains.
- 10 Insert slide grouping and seat on holder ring.
- 11 Rotate slide clips back to hold slide grouping securely.
- 12 Move the chains back in front of the slides.
- 13 Insert lens assembly back into projector with chains hanging down.

The slides should appear upside down.

- 14 Plug in, turn projector on and refocus.
- 15 Tighten lens locking screw.



The perspective slide can project a rectangular window when REVEAL is at an angle to the wall.